




FLEXware Mounting Brackets

System Components and Accessories




FW-MB1




FW-CCB2-T


FW-CCB2



FW-MB3



FW-MB3-F



FW-MB3-S

Features:

- FW-CCB and FW-CCB2 mounting brackets allow OutBack charge controllers to be mounted on the side of FW500-DC, FW1000-DC or GSLC enclosures
- FW-CCB2-T mounting bracket allows OutBack charge controllers to be mounted on the top of FW500-DC or FW1000-DC enclosures
- FW-MB1 mounting bracket allows charge controllers and MATE system display and communications to FLEXware 500, FLEXware 1000 and Radian Series enclosures

FLEXware Mounting Brackets Specifications

02/2019

Model	Description
FW-CCB	Mounting bracket for one side-mounted charge controller on GSLC, FW500 and FW1000 DC enclosures. Includes mounting screws. (Not compatible with FLEXmax 100 charge controller.)
FW-CCB2	Mounting bracket for two side-mounted charge controllers on GSLC, FW500 and FW1000 DC enclosures. Includes mounting screws and flexible conduit. (Not compatible with FLEXmax100 charge controller.)
FW-CCB2-T	Mounting bracket for two top-mounted charge controllers on FW500 and FW1000 DC enclosures. Includes mounting screws. (Not compatible with FLEXmax 100 charge controller.)
FW-MB3	MATE3s mounting bracket for side-mounted display on Radian, GSLC, FW500 and FW1000 DC enclosures. Includes mounting screws and bushings.
FW-MB3-F	Flat-mount MATE3/3S mounting plate for installation over standard electrical boxes. Includes mounting screws
FW-MB3-S	Surface-mount MATE3/3S mounting bracket. Includes mounting screws and bushings.
FW-MB1	FLEXware MATE1 mounting bracket. Includes mounting screws and bushings.
FW-MB2	FLEXware MATE2 mounting bracket. Includes mounting screws and bushings.

*Preliminary specifications are subject to change.

980-0063-01-00 REV A