installation GX Touch 50
CCGX replacement

option A
install including screen

option B
install excluding screen

1. place screen in plastic frame
2. mount steel to screen
3. mount steel to wall, centred in existing opening
4. click cover in place

1. mount plastic frame to steel
2. mount steel to wall, centred in existing opening
3. place screen
4. click cover in place